



Harlequin General Care Guidelines

Applicable to All Harlequin Vinyl Surfaces*

Harlequin vinyl floors are produced from specially formulated PVC, with surface finishes appropriate to the activities to which you are likely to put them. Below are some general care guidelines for users to follow in order to minimize the possibility of damage to the surface of your Harlequin vinyl floor.

Storage and Handling

If your Harlequin floor is not laid permanently always keep it firmly wound onto the cardboard core from the original packaging. This helps to prevent the floor from being flattened or dented and makes handling easier. Never wind up the rolls without a core inside and never store them horizontally on top of each other with no core to support them as this will certainly cause them to flatten and oval resulting in stubborn or permanent ripples. If you do have to store the rolls flat make sure that they are not stacked more than two rolls high and lay no heavy objects on top.

Shoes

Many dance schools tend to avoid outdoor shoes, as grit and dirt can help to scuff the floor and increase the need to clean. If outdoor shoes will be worn make sure that there is an area before stepping onto the dance floor where they can be wiped/cleaned. Stiletto heels should be avoided if they have very sharp edges.

Personal Items

Personal items (coats, bags, purses, beverage containers, food, pets, etc.) should not be placed directly on the dance surface. Dirt, materials, particles and moisture from these items can damage or contaminate the floor.

Furniture/Staging

Any tables and chairs that are placed on the floor should be checked to make sure they have rubber/plastic feet rather than the plain metal tubing, which could cut and stuff the floor.

Avoid dragging any objects over the floor such as tables, chairs, benches or stage equipment as this may scuff and even cut into the floor if they have protruding sharp edges. It is advisable to use spreader boards for any heavy items to prevent any possible damage.

Tap Dancing

No floor, apart from perhaps steel or granite, will stand up indefinitely to loose taps and screws, so shoes should be inspected regularly. Our cushioned vinyls are not recommended for tap dancing.

Temperature

Maintain a constant room temperature between 70 and 80 degrees. Temperature in dance rooms needs to be stabilized at all times, in cold months the room should be warmer.

If you need any further information, please do not hesitate to contact us.

**Not applicable to Harlequin Hi-Shine™*

HARLEQUIN FLOORS

American Harlequin Corporation

1531 Glen Avenue
Moorestown, NJ 08057

(800) 642 6440
contact@harlequinfloors.com
harlequinfloors.com

© Harlequin Floors 4/2019

PHILADELPHIA
FORT WORTH
LOS ANGELES
LAS VEGAS
LONDON
PARIS
BERLIN
LUXEMBOURG
MADRID
SYDNEY
HONG KONG
TOKYO



HARLEQUIN